


CABLE SPLICING SETUP INSTRUCTIONS


1.




2.



3.



4.



5.



KEY

 Clamp  Heat Source